



# INSTALLATION INSTRUCTIONS



## TRUNNION REAR WIPER BLADE



Lift the car's rear wiper arm off the rear screen as far as it will go.



To remove the current wiper blade gently rotate the blade away from the arm until it disengages.



To fit the new Ezywiper blade, align the cross pin on the connector with the grooves on the underside of the arm.



Gently push the Ezywiper blade onto the arm until it locks into place.



Don't forget to remove the protective sleeve from the Ezywiper blade before placing the arm back on the rear screen.

**For installation videos and more info see [ezywiper.co.nz](http://ezywiper.co.nz)**