



# INSTALLATION INSTRUCTIONS



## V-NOTCH REAR WIPER BLADE



1 Lift the car's rear wiper arm off the rear screen then gently tilt the blade until it is at 90° to the arm.



2 Gently rock the blade and lift it upwards so it disengages from the arm.



3 To fit the new Ezywiper blade, hold it at 45° to the arm and place it in position. Gently push the blade down until it locks onto the arm.



4 Rotate the blade towards the arm so it sits in position.



5 Don't forget to remove the protective sleeve from the Ezywiper blade before placing the arm back on the rear screen.

For installation videos and more info see [ezywiper.co.nz](http://ezywiper.co.nz)